

1 Safety Instructions

- Read the user manual completely and carefully before use.
It is part of the product and contains important information for correct use.
- Keep this user manual.
It must be available for uncertainties and passing the product.

Voltage-free only with pulled plug.

- In case of emergency, during thunderstorms and after use, pull the product on its plug housing!
- Do not rotate, bend or mechanically strain otherwise in inserted state.
- Do not open the housing.
- Do not modify product and accessories.
- Do not short-circuit connections and circuits.
- Use product, product parts and accessories only in perfect condition.
- In case of questions, defects, mechanical damage, trouble and other problems, non-recoverable by the documentation, contact your dealer or producer.
- Place, install and transport product, product parts and accessories in a safe way.
- Install the system and devices attached to it in a way that persons cannot be injured, or objects not be damaged for example by dropping or stumbling.

Not meant for children. The product is not a toy!

- Secure packaging, small parts and insulation against accidental use.
- Avoid stresses such as heat and cold, moisture and direct sunlight, microwaves, vibrations and mechanical pressure.

Short circuit to ground

- Do NOT connect already connected devices to other interfaces of the vehicle simultaneously.

2 Description and Function

2.1 Dual-USB Car Quick Charger with USB-C™ PD


The Dual USB car charger charges two devices simultaneously on the cigarette lighter via a USB-A or USB-CTM connection.

- suitable for use in cars with 12 V as well as in trucks with 24 V input voltage
- integrated protection electronics secures the connected devices and offers multiple protection against overcurrent, overload, overheating

2.2 Scope of delivery

Dual-USB Car Quick Charger with USB-C™ PD, User manual

2.3 Operating elements



- 1 Cigarette lighter plug
2 USB-C™ PD (Power Delivery)
3 USB-A QC3.0 (Quick Charge)

2.4 Specifications

Article number	39908	55634
Input	Cigarette lighter plug	
Outputs	USB-C™ PD (Power Delivery) USB-A QC3.0 (Quick Charge)	
Input	12 V - 24 V	12 V - 24 V
Outputs USB-A QC3.0 (Quick Charge)	5 V 3.0 A, 15 W 9 V 2.0 A, 18 W 12 V 1.5 A, 18 W	5 V 3.0 A, 15 W 9 V 3.0 A, 27 W 12 V 2.5 A, 30 W 20 V 1.5 A, 30 W
USB-C™ PD (Power Delivery)	5 V 3.0 A, 15 W 9 V 3.0 A, 27 W 12 V 2.5 A, 30 W 15 V 2.0 A, 30 W* 20 V 1.5 A, 30 W*	5 V 3.0 A, 15 W 9 V 3.0 A, 27 W 12 V 2.5 A, 30 W 15 V 2.0 A, 30 W* 20 V 1.5 A, 30 W*
USB-A USB-C™ USB-A + USB-C™	max. 3.0 A, 18 W max. 3.0 A, 30 W 48 W	max. 3.0 A, 30 W
Dimensions [mm]	61 x 31 x 26	43.5 x 24 x 24
Weight [g]	26	14

*only with 24 V input voltage

Tab.: Specifications

3 Intended Use

We do not permit using the device in other ways like described in chapter „Description and Function“ or in the „Safety Instructions“. Use the product only in dry interior rooms. Not attending to these regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

4 Preparing

- Compare the specifications of all used devices to ensure compatibility.
- Check the scope of delivery for completeness and integrity.

5 Description and Function

- Connect a device to the Dual USB car charger using a suitable USB cable.
- Plug the Dual USB Car Charger into an on-board power outlet.
- Disconnect all connectors after use.



USB cables are not included in scope of delivery.
The product contains no controls that can be operated during use.

6 Maintenance, Care, Storage and Transportation

The product is maintenance-free.

NOTICE!

Material damage

- Clean only with a dry, soft cloth.
- Do not use cleaning agents and chemicals.
- Store cool and dry.
- Store the product out the reach of children and in a dry and dust-protected ambience when not in use.
- Keep and use the original packaging for transport.

7 Disposal Notes

7.1 Product

According to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can pollute our environment.

As a consumer, you are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the user's manual, or at the packaging alludes to these terms. With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environmental protection.

WEEE No: 82898622

7.2 Packaging

Packaging can be disposed of free of charge at the suitable collection points – paper belongs in paper bins, plastics belong in yellow sacks and glass belongs in used glass bins.

DE4535302615620

8 EU Declaration of Conformity

With the CE sign, Gobay®, a registered trademark of the Wentronic GmbH ensures, that the product is conformed to the basic European standards and directives.

9 Symbols used

Direct current	IEC 60417- 5031	
For indoor use only	IEC 60417- 5957	
Recycling	ISO 7001 - PI PF 066	